



SIDING TO THIN TECH TRANSITION

CLASSIC

NOTE: FASTENER PENETRATION - WOOD STUD- 1 1/4" MIN., STEEL STUD - 3 THREADS MIN., CONCRETE -1" MIN.

* USE BACKER ROD WHERE JOINT DEPTH >3/4"