



SIDING TO THIN TECH TRANSITION (ALTERNATE)

CLASSIC

NOTE: FASTENER PENETRATION - WOOD STUD- 1 1/4" MIN., STEEL STUD - 3 THREADS MIN., CONCRETE - 1" MIN.
 * USE BACKER ROD WHERE JOINT DEPTH >3/4"